


# INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT CALIBRE NO. JS05/15/25 STOPWATCH FUNCTION: SMALL SECOND HAND TIME MEASUREMENT UP TO 29min 59 sec BATTERY: SR621SW

#### A) DISPLAYS AND BUTTONS B) SETTING THE TIME C) SETTING THE DATE D) USING THE STOPWATCH

E) STOPWATCH RESET

A) DISPLAYS AND BUTTONS



## **B) SETTING THE TIME**

- 1. Pull the crown out to the 2nd Click Position.
- 2. Turn the crown to set hour and minute hands.
- 3. After the time has been set, push the crown back to the Normal position.

## **C) SETTING THE DATE**


- 1. Pull the crown out to the 1st Click Position.
- 2. Turn the crown clockwise to set the date.
- \* If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.
- 3. After the date has been set, push the crown back to the Normal position.

## **D) USING THE STOPWATCH**

This stopwatch is able to measure and display time in 1/1 second united up to maximum of 30 minutes. Stopwatch will stop automatically after running continuously for 30 minutes.

#### [Measuring time with the stopwatch]

- 1. Press button "A" to start the stopwatch.
- 2. The stop watch can be started and stopped each time button "A" is pressed.
- 3. Pressing button "B" resets the stopwatch and stopwatch minute and second hands return to their Zero positions.



#### E) STOPWATCH RESET (INCL. AFTER REPLACING BATTERY)

This procedure should be performed when the stopwatch second & minute hand does not return to the Zero position.

- 1. Pull the crown out to the 2nd Click Position.
- Press the button "A" to set the stopwatch second hand forward. Press the button "B" to set the stopwatch second hand back.
  - \* The stopwatch minute hand is synchronized with stopwatch second hand.
  - \* The stopwatch second hand can be advanced rapidly by continuously pressing button "A" or "B".
- 3. Once the both hands been zeroed, reset the time and return the crown to its normal position.